## **4-SIDED BLINDS**



## **Roof Support (optional):**

This product is not designed for sustained snowload. If the product will be unattended for any period of time through the winter months, we recommend a  $2 \times 4$  support post be placed in the center of the structure.

We recommend a 82" length. (This length may vary depending on the ground the shelter is sitting on).

Cut a 2 x 4 to this measurement. Lodge the support between the ground and the roof when not in the blind. This will help support the roof under heavy snowfall.

NOTE: If your roof does collapse, it can be reset by disconnecting the roof and placing it on the ground. Once its on the ground, stand on the roof to push the dent out and back to shape.

