

**TOOLS REQUIRED:**

Philips Screwdriver


**PARTS INCLUDED:**

- (A) Outer Handle
- (B) Inner Handle
- (C) Screw

Insert the round outer handle (A) into the door from the outside, and the inner handle (B) into the door from the inside.

Ensure that the inner handle (B) is aligned horizontally and pointing away from the door hinges.

Insert screw (C) through the outer handle (A) and into the inner handle (B), then tighten the screw securely.



If you need additional assistance please contact us at the email or number below.

[customerservice@kloutdoor.com](mailto:customerservice@kloutdoor.com), Customer Service: 231-332-1700 #2